

DIY Static Shade System

5 SIMPLE STEPS

Components Required:

1 x Polytex DIY Shade Kit
4 x Steel Posts 200mm Dia x 5mm
2m³ of Concrete
600mm Post Hole Borer
Welder

1. Purchase a Polytex DIY Static Shade System Kit.

Package includes:

- Shade Sail 276gsm Cloth Knitted Monofilament UV Treated 80-90% Shade
- Colour: Black
- Tensioning Kit for securing to posts

2. Decide the best position to install the shade and bore 4 holes (600mm dia x 1500mm deep) at the required dimensions of your selected kit.

3. Weld the tensioning kits to the top of the posts.

4. Concrete 200mm steel posts in place with slight outwards tilt.

- Ensure two diagonal posts are at least 1m lower than the other two posts to create a twist in the fabric for water runoff.

5. Attach the shade cloth and tension until tight.

Congratulations for completing your Polytex Static Shade System!

Recommended Feedlot Pen Shade:

Sheep: >0.8m² per head
Cattle: >2m² per head

Call Polytex **1300 059 003**
for further tips

